



HyperWare™ Retail Software

T7Plus
with SPOS 09A



Note: Printing a second receipt, the customer receipt, is an option for all transactions.

CREDIT SALE	
Terminal Display	Action
SWIPE CUSTOMER CARD	Swipe credit card through card reader.
AMOUNT \$0.00	Enter amount of sale, then press ENTER .
COMMS	Terminal dials host.
RESPONSE	Approval number is displayed on screen, and printed on receipt.
Approval 123456	

DEBIT SALE	
Terminal Display	Action
SWIPE CUSTOMER CARD	Press Debit button.
SWIPE CUSTOMER CARD	Swipe card through card reader.
AMOUNT \$0.00	Enter amount of sale, press ENTER .
Waiting for PIN	Customer enters PIN on attached PIN pad.
COMMS	Terminal dials host.
Response	Approval number is displayed on screen, and printed on receipt.
Approval 123456	

EBT SALE	
Terminal Display	Action
SWIPE CUSTOMER CARD	Press E-Mail button.
SWIPE CUSTOMER CARD	Swipe card through card reader.
1-FOOD STAMP 2-CASH BENEFIT	Press 1 for FOOD STAMP or 2 for CASH BENEFIT, press ENTER .
SALE AMOUNT \$0.00	Enter amount of sale, press ENTER .
Waiting for PIN	Customer enters PIN on attached PIN Pad.
COMMS	Terminal dials host.
Response	Approval number is displayed on screen, and printed on receipt.
Approval 123456	

CREDIT REFUND	
Terminal Display	Action
SWIPE CUSTOMER CARD	Press Refund button
SWIPE CUSTOMER CARD	Swipe card through card reader.
AMOUNT \$0.00	Enter amount of refund, press ENTER .
COMMS	Terminal dials host.
Response	Approval number is displayed on screen, and printed on receipt.
Approval 123456	

DEBIT REFUND	
Terminal Display	Action
SWIPE CUSTOMER CARD	Press Debit and Refund button
SWIPE CUSTOMER CARD	Swipe card through card reader.
AMOUNT \$0.00	Enter amount of refund, press ENTER .
Waiting for PIN	Customer enters PIN on attached PIN pad.
COMMS	Terminal dials host.
Response	Approval number is displayed on screen, and printed on receipt.
Approval 123456	

REPRINT LAST RECEIPT	
Terminal Display	Action
SWIPE CUSTOMER CARD	Press Function, 72 , then Enter
1-MERCHANT RECPT	Press 1 for MERCHANT RECEIPT or
2-CUSTOMER RECPT	Press 2 for CUSTOMER RECEIPT then ENTER
REPRINT COMPLETE	Receipt is printed.

OFFLINE/FORCE	
Terminal Display	Action
SWIPE CUSTOMER CARD	Press Off Line button.
OFFLINE MODE	Enter card number, press ENTER .
ENTER ACCOUNT NUMBER	
EXPIRATION DATE	Enter expiration date, press ENTER
AMOUNT \$0.00	Enter amount of sale, press ENTER
ENTER APPROVAL CODE	Enter approval code from voice authorization.
TRANSACTION ACCEPTED	Offline/Force is complete.

BATCH REPORT (SUMMARY)	
Terminal Display	Action
SWIPE CUSTOMER CARD	Press Reports button.
3-AUDIT 4-SUMMARY	Press 4 , then ENTER .
SCANNING BATCH	Terminal scans for Batch Totals and prints Summary Report.

BATCH REPORT (AUDIT)	
Terminal Display	Action
SWIPE CUSTOMER CARD	Press Reports button.
3-AUDIT 4-SUMMARY	Press 3 , then ENTER .
HOST NUMBER	Enter Host Number or "0" for all hosts
PRINTING	Audit report is printed.

BATCH SETTLE	
Terminal Display	Action
SWIPE CUSTOMER CARD	Press Settle button.
ENTER PASSWORD	Enter merchant password 0000, then press ENTER .
HOST NUMBER	Press 0 for all hosts or enter Host Number, then ENTER .
SCANNING BATCH	Terminal scans for Batch Totals.
SALES TOTAL CORRECT?	Press YES to confirm sale.
REFUND TOTAL CORRECT?	Press YES to confirm refund total.
SCANNING BATCH	Terminal scans for Batch Totals.
COMMS	Terminal dials host.
RESPONSE	Settlement is complete.
Approval 123456	
SCANNING BATCH	Settlement report is printed.